
Installation Instructions




MIT



ZMIT201404NA

- 1/8 **--**

Installation Dimension



2/8 =


Installation Dimension

Unit: mm

5	Step	Component	Α	В	С	D
	1	MIT21	100	30	φ <i>4.5</i>	112
	2	MIT22	115	35	φ5.5	125
	3	MIT23	143	45	φ <i>5.5</i>	201
	4	MIT24	204	65	φ6.5	235

— 3/8 **—**

Installation



4/8 =




WARNING

NOARK IS NOT LIABLE FOR THE MISAPPLICATION OR MISSAPPLICATION OF IT'S PRODUCTS.

ONLY SKILLED QUALIFIED PERSON MAY CARRY OUT THE INSTALLATION


Installation



ZMIT201404NA


—5/8 **—**

Installation



---6/8 --


Installation



—7/8 **—**

Installation

4



Notes

Step	Component	Operating
1	screws	taking away
2	screws	fastening

-8/8 **-**

Noglk



Printed with environment-friendly paper Copyright Noark. All Rights Reserved www.noark-electric.com 04/2014